

Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Казахстан (7273)495-231

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Таджикистан (992)427-82-92-69

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: hmh@nt-rt.ru || <https://hamiltonbeach.nt-rt.ru/>

Модель 62664. Пятискоростной ручной миксер Hamilton Beach Professional с легко очищаемыми венчиками.

FEATURES



- Easy Clean beaters won't clog and provide great mixing performance
- Ultimate mixing power and control
- Reduces messy splatters with Slow Start™ technology
- Includes storage case with 2 Easy Clean beaters, 2 wire beaters & whisk
- Easily handle mixing jobs with 5 speeds and QuickBurst™ function
- Lockable swivel cord
- 5 year limited warranty

Dimensions: 11.8 H x 7.6 W x 3.3 D

DETAILS

Mix your recipes effortlessly with the Hamilton Beach® Professional 5 Speed Hand Mixer with Easy Clean beaters. The innovative Easy Clean beaters won't clog and provide great mixing performance. You'll enjoy ultimate mixing power and control because the professional-grade DC motor powers through the thickest dough and maintains constant speed no matter what you're mixing. When you mix on the lowest speed, you'll have more control with Slow Start™ technology, which reduces messy splatters and has a starting speed that's nearly half as slow as a traditional mixer. The Hamilton Beach Professional 5 Speed Hand Mixer comes with a storage case, 2 Easy Clean beaters, 2 stainless steel wire beaters and a whisk to cover every mixing task. The QuickBurst™ function provides an extra burst of power at every speed and the lockable swivel cord stays out of your way and adjusts for left- and right-handed users. After mixing, the quick-release trigger makes it easy to remove the attachments, which are dishwasher safe for easy cleanup. The attractive metallic silver color with chrome bands looks great in any kitchen. Includes 5 year limited warranty.

Easy clean beaters won't clog and provide great mixing performance

Their smooth, innovative design glides through ingredients without clogging, saving you time and aggravation every time you mix.

Ultimate mixing power and control

Whether you're mixing chocolate chip or peanut butter cookie dough, the hand mixer with DC motor powers through the thickest dough and maintains constant speed no matter what you're mixing.

Reduces messy splatters with slow start™ technology

This 5 speed hand mixer's starts slowly on the lowest speed to reduce messy splatters, making it easier to gradually add ingredients.

Includes storage case with 2 easy clean beaters, 2 stainless steel wire beaters and whisk

The snap-on storage case means no more lost beaters. The Easy Clean beaters, stainless steel wire beaters and whisk are dishwasher safe for easy cleanup.

Easily handle mixing jobs with 5 speeds and quickburst™ function

Push the QuickBurst™ function for an extra punch of power at any of the 5 speeds on this Hamilton Beach mixer.

Модель 62651. Пятискоростной ручной миксер Hamilton Beach Professional (черный).



FEATURES

- Powerful DC motor with slow start
- Rotating speed dial has 5 speeds with QuickBurst™
- Snap-on storage case for attachments
- Convenient eject trigger
- Includes stainless steel wire beaters & whisk
- 5 year warranty
- Lockable swivel cord for right or left hand use
- DETAILS

- Whether it's lighter-than-air whipped cream or chewy chocolate chip cookie dough, you can mix ingredients effortlessly with the Hamilton Beach

Professional 5-Speed Hand Mixer. Lightweight and powerful, this mixer has a slow start that prevents splatters, no matter what you're mixing. Push the QuickBurst button for an extra punch of power at any of the five levels. A lockable swivel cord, snap-on storage case and trigger-release makes mixing easy from start to finish.

- **Powerful, Effortless Mixing**

From mashed potatoes to whipped cream, this professional-grade hand mixer gives you the power and control to mix and blend with ease.

- **Slow Start Reduces Splatters**

Prevent clouds of flour and splatters of dough by starting slow and gently increasing speed. This hand mixer's first speed is similar to Soft Start* KitchenAid mixers. The vent design and the matte finish make it easy to wipe the mixer clean.

- **Snap-On Storage Case with Beaters & Whisk**

Keep everything in one place. Stainless steel beaters and whisk are dishwasher-safe.

- **5 Speeds with QuickBurst at Every Level**

Adds a quick burst for a slow, gentle mix or for a fast whip.

- **Swivel Cord Lock**

Swivel cord lock lets you adjust the cord to stay out of your way during mixing, whether you're left or right-handed.

- **Trigger Release for Attachments**

With a quick pull of the trigger, attachments release when you're done mixing.

- **KITCHENAID and SOFT START are registered trademarks of Whirlpool Corporation. Use of the marks does not imply any affiliation with or endorsement by Whirlpool Corporation.*

Модель 62652. Пятискоростной ручной миксер Hamilton Beach Professional (белый).



FEATURES

- Powerful DC motor with slow start
- Rotating speed dial has 5 speeds with QuickBurst™
- Snap-on storage case for attachments
- Convenient eject trigger
- Includes stainless steel wire beaters & whisk
- 5 year warranty
- Lockable swivel cord for right or left hand use

Dimensions: 10.1 H x 8.7 W x 3.2 D

DETAILS

Powerful mixing at home

Whether it's lighter-than-air whipped cream or chewy chocolate chip cookie dough, you can mix ingredients effortlessly with the Hamilton Beach Professional 5-Speed Hand Mixer. Lightweight and powerful, this mixer has a slow start that prevents splatters, no matter what you're mixing. Push the QuickBurst button for an extra punch of power at any of the five levels. A lockable swivel cord, snap-on storage case and trigger-release makes mixing easy from start to finish.

Powerful, Effortless Mixing

From mashed potatoes to whipped cream, this professional-grade hand mixer gives you the power and control to mix and blend with ease.

Slow Start Reduces Splatters

Prevent clouds of flour and splatters of dough by starting slow and gently increasing speed. This hand mixer's first speed is similar to Soft Start* KitchenAid mixers. The vent design and the matte finish make it easy to wipe the mixer clean.

Snap-On Storage Case with Beaters & Whisk

Keep everything in one place. Stainless steel beaters and whisk are dishwasher-safe.

5 Speeds with QuickBurst at Every Level

Adds a quick burst for a slow, gentle mix or for a fast whip.

Swivel Cord Lock

Swivel cord lock lets you adjust the cord to stay out of your way during mixing, whether you're left or right-handed.

Trigger Release for Attachments

With a quick pull of the trigger, attachments release when you're done mixing.

**KITCHENAID and SOFT START are registered trademarks of Whirlpool Corporation. Use of the marks does not imply any affiliation with or endorsement by Whirlpool Corporation.*

Модель 62653. Пятискоростной ручной миксер Hamilton Beach Professional (красный).

FEATURES



- Slow Starting Speed - reduces splatter same as KitchenAid®*
- Mixing control and power in every recipe
- Powerful DC motor mixes with ease
- Slow starting speed reduces splatter
- Includes snap-on storage case with beaters, dough hooks & whisk
- Lockable swivel cord for right- or left-hand use
- Convenient snap-on storage case
- 5 speeds with QuickBurst™ at every level
- Quick-release trigger removes beaters
- 5 year limited warranty

* KITCHENAID and SOFT START are registered trademarks of Whirlpool Corporation. Use of the marks does not imply any affiliation with or endorsement by Whirlpool Corporation.

Dimensions: 10.1 H x 8.7 W x 3.2 D

DETAILS

Mix any recipe effortlessly with the Hamilton Beach® Professional 5-Speed Hand Mixer. This electric mixer has a slow start that prevents splatters, a QuickBurst™ at every level and a snap-on storage case. The attractive metallic red color with chrome bands looks great in any kitchen.

Powerful, Effortless Mixing

From mashed potatoes to whipped cream, this professional-grade hand mixer gives you the power and control to mix and blend with ease.

Slow Start Reduces Splatters

Prevent clouds of flour and splatters of dough by starting slow and gently increasing speed. This hand mixer's first speed is similar to Soft Start®* KitchenAid® mixers. The vent design and the finish make it easy to wipe the mixer clean.

Snap-On Storage Case for Attachments

Keep everything in one place. Stainless steel beaters, dough hooks and whisk mix everything from light and airy whipped cream to sticky bread dough.

5 Speeds with QuickBurst™ at Every Level

Adds a quick burst of power for a slow, gentle mix or for a fast whip.

Swivel Cord Lock

Swivel cord lock lets you adjust the cord to stay out of your way during mixing, whether you're left or right-handed.

Quick-Release Trigger

With a quick pull of the trigger, attachments release when you're done mixing.

**KITCHENAID and SOFT START are registered trademarks of Whirlpool Corporation. Use of the marks does not imply any affiliation with or endorsement by Whirlpool Corporation.*

Модель 62657. Семискоростной ручной миксер Hamilton Beach Professional (серебристый).

FEATURES



- Slow Starting Speed - reduces splatter same as KitchenAid®*
- Mixing control and power in every recipe
- Powerful DC motor mixes with ease
- Slow starting speed reduces splatter
- Includes storage case with Soft Scrape™ beaters, whisk & dough hooks
- Lockable swivel cord for right- or left-hand use
- Convenient snap-on storage case
- 7 speeds with QuickBurst™ at every level
- Quick-release trigger removes beaters
- 5 year limited warranty

* KITCHENAID and SOFT START are registered trademarks of Whirlpool Corporation. Use of the marks does not imply any affiliation with or endorsement by Whirlpool Corporation.

Dimensions: 10.1 H x 8.7 W x 3.2 D

DETAILS

Whether it's a fluffy meringue or chewy chocolate chip cookie dough, you can mix ingredients effortlessly with the Hamilton Beach® Professional 7 Speed Hand Mixer. Lightweight and powerful, this mixer has a slow start that prevents splatters, no matter what you're mixing. Push the QuickBurst™ button for an extra punch of power at any of the seven speeds. A lockable swivel cord, snap-on storage case and trigger-release makes mixing easy from start to finish. The attractive metallic silver color with chrome bands looks great in any kitchen.

Powerful, Effortless Mixing

From mashed potatoes to whipped cream, this professional-grade hand mixer gives you the power and control to mix and blend with ease.

Slow Start Reduces Splatters

Prevent clouds of flour and splatters of dough by starting slow and gently increasing speed. This hand mixer's first speed is similar to Soft Start®* KitchenAid® mixers. The vent design and the matte finish make it easy to wipe the mixer clean.

Snap-On Storage Case with Accessories

The 7 Speed Hand Mixer includes Soft Scrape™ beaters, whisk and dough hooks. A snap-on storage case keeps all accessories organized neatly.

7 Speeds with QuickBurst™ at Every Level

Adds a quick burst for a slow, gentle mix or for a fast whip.

Quick-Release Trigger

With a quick pull of the trigger, attachments release when you're done mixing.

Swivel Cord Lock

Swivel cord lock lets you adjust the cord to stay out of your way during mixing, whether you're left or right-handed.

5 Year Limited Warranty

Hamilton Beach® Professional 7 Speed Hand Mixer's exceptional performance and superior durability is backed by a 5 year limited warranty.

* KITCHENAID and SOFT START are registered trademarks of Whirlpool Corporation. Use of the marks does not imply any affiliation with or endorsement by Whirlpool Corporation.

Hamilton Beach Professional

Inspired by our 100 years of experience designing products used in commercial kitchens, Hamilton Beach® Professional is a line of countertop kitchen appliances with professional-level components designed to deliver exceptional performance and superior durability for the serious home cook. Thoughtful features like precise speed control, convenient pre-programmed settings, and powerful motors to push through any job will make your time in the kitchen easier and more enjoyable.

Модель 62655. Семискоростной ручной миксер Hamilton Beach Professional (матово черный).



FEATURES

- 5 year warranty
- Slow Starting Speed - reduces splatter same as KitchenAid®*
- Mixing control and power in every recipe
- Powerful DC motor mixes with ease
- Slow starting speed reduces splatter
- Includes storage case with Soft Scrape™ beaters, whisk & dough hooks
- Lockable swivel cord for right- or left-hand use
- Convenient snap-on storage case
- 7 speeds with QuickBurst™ at every level
- Quick-release trigger removes beaters

Dimensions: 10.1 H x 8.7 W x 3.2 D

DETAILS

7 speeds for powerful, effortless mixing at home.

Whether it's a fluffy meringue or chewy chocolate chip cookie dough, you can mix ingredients effortlessly with the Hamilton Beach Professional 7 Speed Hand Mixer. Lightweight and powerful, this mixer has a slow start that prevents splatters, no matter what you're mixing. Push the QuickBurst button for an extra punch of power at any of the seven speeds. A lockable swivel cord, snap-on storage case and trigger-release makes mixing easy from start to finish.

Powerful, Effortless Mixing

From mashed potatoes to whipped cream, this professional-grade hand mixer gives you the power and control to mix and blend with ease.

Slow Start Reduces Splatters

Prevent clouds of flour and splatters of dough by starting slow and gently increasing speed. This hand mixer's first speed is similar to Soft Start* KitchenAid mixers. The vent design and the matte finish make it easy to wipe the mixer clean.

Snap-On Storage Case with Accessories

The 7 Speed Hand Mixer includes Soft Scrape beaters, whisk and dough hooks. A snap-on storage case keeps all accessories organized neatly.

7 Speeds with QuickBurst at Every Level

Adds a quick burst for a slow, gentle mix or for a fast whip.

Quick-Release Trigger

With a quick pull of the trigger, attachments release when you're done mixing.

Swivel Cord Lock

Swivel cord lock lets you adjust the cord to stay out of your way during mixing, whether you're left or right-handed.

5 Year Limited Warranty

Hamilton Beach Professional 7 Speed Hand Mixer's exceptional performance and superior durability is backed by a 5 year limited warranty.

** KITCHENAID and SOFT START are registered trademarks of Whirlpool Corporation. Use of the marks does not imply any affiliation with or endorsement by Whirlpool Corporation.*

Модель 62656. Семискоростной ручной миксер Hamilton Beach Professional (белый).



FEATURES

- Slow Starting Speed - reduces splatter same as KitchenAid®*
 - Mixing control and power in every recipe
 - Powerful DC motor mixes with ease
 - Slow starting speed reduces splatter
 - Includes storage case with Soft Scrape™ beaters, whisk & dough hooks
 - Lockable swivel cord for right- or left-hand use
 - Convenient snap-on storage case
 - 7 speeds with QuickBurst™ at every level
- Quick-release trigger removes beaters

** KITCHENAID and SOFT START are registered trademarks of Whirlpool Corporation. Use of the marks does not imply any affiliation with or endorsement by Whirlpool Corporation.*

Dimensions: 10.1 H x 8.7 W x 3.2 D

DETAILS

Whether it's a fluffy meringue or chewy chocolate chip cookie dough, you can mix ingredients effortlessly with the Hamilton Beach Professional 7 Speed Hand Mixer. Lightweight and powerful, this mixer has a slow start that prevents splatters, no matter what you're mixing. Push the QuickBurst button for an extra punch of power at any of the seven speeds. A lockable swivel cord, snap-on storage case and trigger-release makes mixing easy from start to finish.

Powerful, Effortless Mixing

From mashed potatoes to whipped cream, this professional-grade hand mixer gives you the power and control to mix and blend with ease.

Slow Start Reduces Splatters

Prevent clouds of flour and splatters of dough by starting slow and gently increasing speed. This hand mixer's first speed is similar to Soft Start* KitchenAid mixers. The vent design and the matte finish make it easy to wipe the mixer clean.

Snap-On Storage Case with Accessories

The 7 Speed Hand Mixer includes Soft Scrape beaters, whisk and dough hooks. A snap-on storage case keeps all accessories organized neatly.

7 Speeds with QuickBurst at Every Level

Adds a quick burst for a slow, gentle mix or for a fast whip.

Quick-Release Trigger

With a quick pull of the trigger, attachments release when you're done mixing.

Swivel Cord Lock

Swivel cord lock lets you adjust the cord to stay out of your way during mixing, whether you're left or right-handed.

5 Year Limited Warranty

Hamilton Beach Professional 7 Speed Hand Mixer's exceptional performance and superior durability is backed by a 5 year limited warranty.

* KITCHENAID and SOFT START are registered trademarks of Whirlpool Corporation. Use of the marks does not imply any affiliation with or endorsement by Whirlpool Corporation.

Hamilton Beach Professional

Inspired by our 100 years of experience designing products used in commercial kitchens, Hamilton Beach Professional is a line of countertop kitchen appliances with professional-level components designed to deliver exceptional performance and superior durability for the serious home cook. Thoughtful features like precise speed control, convenient pre-programmed settings, and powerful motors to push through any job will make your time in the kitchen easier and more enjoyable.

Модель 62658. Семискоростной ручной миксер Hamilton Beach Professional (бирюзовый).



FEATURES

- Powerful DC motor with slow start
- Rotating speed dial has 5 speeds with QuickBurst™
- Snap-on storage case for attachments
- Convenient eject trigger
- Includes stainless steel wire beaters & whisk
- 5 year warranty
- Lockable swivel cord for right or left hand use

Dimensions: 10.1 H x 8.7 W x 3.2 D

DETAILS

Powerful mixing at home

Whether it's lighter-than-air whipped cream or chewy chocolate chip cookie dough, you can mix ingredients effortlessly with the Hamilton Beach Professional 5-Speed Hand Mixer. Lightweight and powerful, this mixer has a slow start that prevents splatters, no matter what you're mixing. Push the QuickBurst button for an extra punch of power at any of the five levels. A lockable swivel cord, snap-on storage case and trigger-release makes mixing easy from start to finish.

Powerful, Effortless Mixing

From mashed potatoes to whipped cream, this professional-grade hand mixer gives you the power and control to mix and blend with ease.

Slow Start Reduces Splatters

Prevent clouds of flour and splatters of dough by starting slow and gently increasing speed. This hand mixer's first speed is similar to Soft Start* KitchenAid mixers. The vent design and the matte finish make it easy to wipe the mixer clean.

Snap-On Storage Case with Beaters & Whisk

Keep everything in one place. Stainless steel beaters and whisk are dishwasher-safe.

5 Speeds with QuickBurst at Every Level

Adds a quick burst for a slow, gentle mix or for a fast whip.

Swivel Cord Lock

Swivel cord lock lets you adjust the cord to stay out of your way during mixing, whether you're left or right-handed.

Trigger Release for Attachments

With a quick pull of the trigger, attachments release when you're done mixing.

**KITCHENAID and SOFT START are registered trademarks of Whirlpool Corporation. Use of the marks does not imply any affiliation with or endorsement by Whirlpool Corporation.*

По вопросам продажи и поддержки обращайтесь:

Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Казахстан (7273)495-231

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Таджикистан (992)427-82-92-69

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: hmh@nt-rt.ru || <https://hamiltonbeach.nt-rt.ru/>