

Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Казахстан (7273)495-231

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Таджикистан (992)427-82-92-69

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: hmh@nt-rt.ru || <https://hamiltonbeach.nt-rt.ru/>

Модель 62690. Шестискоростной ручной миксер с функцией QuickBurst с защелкивающимся кейсом (черный).



FEATURES

- No more lost beaters — they conveniently store in the snap-on case
- Easily handle every mixing job with 6 speeds, and QuickBurst™ for extra power
- Mix, whip, and cream with 2 traditional beaters and a whisk
- Avoid messy spills with Bowl Rest™ – it stabilizes the mixer on the edge of the bowl
- Cord is designed to stay out the way when mixing
- Designed for fast and easy mixing
- Effortlessly mix ingredients for all your recipes with 250 watts of peak power

Dimensions: 11 H x 8.6 W x 3.8 D

DETAILS

The Hamilton Beach® 6 Speed Hand Mixer with QuickBurst™ includes a storage case that easily snaps onto the mixer to instantly store attachments and prevent lost beaters. The electric hand mixer has 6 speeds to easily handle every mixing job, from making chunky chocolate chip cookies to frothy whipped cream. The QuickBurst™ button gives you an added burst of power when you need it at any speed level. Mix, whip and cream with the 2 traditional beaters and a whisk that are included. You can start mixing everything from cake batter to egg whites right out of the box. Avoid messy spills with the convenient Bowl Rest™ feature that stabilizes the mixer on the edge of the bowl when the mixer is not in use. The patent-pending cord is designed to conveniently stay out of your way when mixing, whether you're right- or left-handed. The hand mixer also features a modern design that's lightweight and easy to use, yet has 250 watts of peak power to mix ingredients for all your favorite recipes, whether you're making a casserole for your family's dinner or a batch of decadent brownies for a party.

No more lost beaters

The storage case easily snaps onto the electric hand mixer. It holds the included attachments to prevent lost beaters and eliminate clutter.

Easily handle every mixing job

This versatile Hamilton Beach hand mixer has 6 different speed options, plus QuickBurst™ at any speed level for those times when you need an extra burst of power.

Mix, whip, and cream with 2 traditional beaters and whisk

The hand mixer includes everything you need to start mixing. It comes with 3 dishwasher safe attachments: 2 traditional beaters and a whisk.

Avoid messy spills with bowl rest™

Bowl Rest™ conveniently stabilizes the mixer on the edge of the bowl when the mixer is not in use, to eliminate messy spills, while freeing your hands.

Cord is designed to stay out of the way

The patent-pending cord on the hand mixer with storage case is designed to stay out the way for both left- and right-handed users when mixing

Модель 62691. Ручной миксер с защелкивающимся кейсом (черный).



2020

FEATURES

- No more lost beaters — they conveniently store in the snap-on case
- Includes 5 dishwasher safe attachments
- Reduce messy splatters with slower first speed
- Easily mix ingredients for all your recipes with 275 watts of peak power
- Versatile with 6 speeds, and QuickBurst™ for extra power
- Free your hands with Bowl Rest™ — it stabilizes the mixer on the edge of the bowl
- From America's #1 hand mixer brand*
- *Source: The NPD Group Inc. 12 months ending April

Dimensions (inches): 8.2 H x 11.5 W x 4.1 D

DETAILS

Prevent lost beaters and eliminate mess with the Hamilton Beach® 6 Speed Hand Mixer with snap-on case. The storage case stores the 5 included dishwasher safe attachments. The mixer comes with everything you need to start mixing. It includes 2 traditional beaters, a whisk, and 2 dough hooks. With 275 watts of peak power, the hand mixer easily mixes the ingredients for all your favorite recipes, whether you're adding heavy ingredients like nuts and candies to cookie dough or making light, fluffy meringue to top a homemade pie. This versatile mixer has 6 different speed options, plus QuickBurst™ at any speed level for those times when you need an extra burst of power. The slower first speed reduces messy splatters by keeping ingredients in the bowl when mixing. It's perfect for folding dry ingredients like flour into liquids. Bowl Rest™ conveniently stabilizes the mixer on the edge of the bowl when the mixer is not in use, to eliminate messy spills, while freeing your hands. You'll cook with confidence with this hand mixer from America's #1 hand mixer brand.*

No more lost beaters

The storage case easily snaps onto the electric hand mixer. It holds the included attachments to prevent lost beaters and eliminate clutter. A convenient access door makes it easy to add or remove attachments.

Includes 5 attachments

The hand mixer with storage case includes everything you need to start mixing. It comes with 5 dishwasher safe attachments: 2 traditional beaters, a whisk, and 2 dough hooks.

Reduce messy splatters

The Hamilton Beach hand mixer has a slower first speed that helps keep ingredients in the bowl when mixing. It's perfect for folding in dry ingredients like flour or combining liquids.

Mix ingredients for all your recipes

With 275 watts of peak power, the hand mixer easily mixes ingredients for all your favorite recipes, whether you're adding nuts and candies to cookie dough or making light, fluffy meringue to top a homemade pie.

Easily handle every mixing job

The versatile Hamilton Beach hand mixer has 6 different speed options, plus QuickBurst™ at any speed level for those times when you need an extra burst of power.

Модель 62635. Ручной миксер с защелкивающимся кейсом.

FEATURES



- Snap-on storage case
- 275 Watts peak power
- Bowl Rest™ feature
- 6 speeds with QuickBurst™ butto
- Slower first speed reduces messy splatters
- Larger control dial for easier use
- 3 attachments: 2 traditional beaters and 1 whisk

Dimensions (inches): 9.9 H x 6.7 W x 9.1 D

DETAILS

Mix and whip with power, convenience and comfort.

Whip up an airy meringue or decadent cake with the Hamilton Beach® Hand Mixer. This versatile mixer is your go to appliance for mixing, whisking and folding. A built in bowl rest makes it easier to set the mixer down when adding ingredients. The control dial is large for ease of use and touts six speeds, including a burst function for additional power at any speed. The Hamilton Beach® Hand Mixer is not just about performance – it's also designed for easy storage. A convenient snap-on case keeps attachments together, so you don't have to search for them each time.

Reduce Splatters with Slower Speed

Incorporating flour or other dry ingredients can sometimes be a mess with traditional hand mixers. The slower first speed gives you more control and prevents splattering.

Snap-On Storage Case

No more digging through the drawers to find your mixer attachments. A storage case perfectly fits all the attachments and cord. It then snaps onto the mixer, keeping everything together in one place.

Bowl Rest

Take a pause to read the recipe or add the next ingredient without wondering where to set the mixer. A built in groove lets you rest the mixer over the bowl, so drips go where they belong and not all over your countertop.

Attachments Included

Get mixing and whisking right away. Easy to clean set of traditional beaters and a whisk are included.

Модель 62648. Ручной миксер с футляром для хранения.

FEATURES



- Storage case for attachments & mixer
- 6 speeds with QuickBurst™
- Set includes whisk and 2 SoftScape™ beaters
- SoftScape™ beaters won't scratch bowls or nonstick pots
- 275 watts peak power
- QuickBurst™ button provides extra power at any speed
- Bowl Rest™ feature
- Stainless body
- Rubber grip

Dimensions (inches): 5.1 H x 8.3 W x 3.5 D

DETAILS

The Hamilton Beach® Performance Hand Mixer features 6 speeds and a QuickBurst™ button. Everything you need to start mixing is included — a whisk and 2 SoftScape™ beaters — plus you get a storage case for keeping everything conveniently in one place. Exclusive SoftScape™ beaters are designed to mix faster and clog less, so you can prepare recipes quicker and spend less time in the kitchen. SoftScape™ beaters won't scratch bowls or nonstick pots. The mixer body is made from durable stainless steel and the rubber grip handle makes it easy to handle. With 275 watts of peak power, this mixer will make easy work of all your favorite recipes, whether you're making a large batch of chocolate brownies loaded with nuts or frothy whipped cream to top a tasty fruit-filled pie.

6 speeds with quickburst™ button

This versatile hand mixer has 6 different speed options, plus a quickburst™ button for those times when you need an extra burst of power.

Storage case, whisk, and 2 softsrape™ beaters included

The electric hand mixer with storage case includes everything you need. And the mixer and all the accessories store neatly inside the case.

Beaters designed for fast and easy mixing

Exclusive softsrape™ beaters are taller and designed to mix faster and clog less. Softsrape™ beaters also will not scratch bowls and nonstick pots either.

275 watts peak power

Easily mix the ingredients in all your favorite recipes with the Hamilton Beach hand mixer, whether you're making a large batch of decadent brownies with nuts or frothy whipped cream for a pie.

Stainless body with bowl rest™ feature

The body is made from durable stainless steel and includes a Bowl Rest™ feature for sitting on the edge of bowls and pans.

Модель 62669. Ручной миксер с защелкивающимся кейсом (белый).



FEATURES

- 6 speeds
- Snap-on storage case
- Easy-access door on case
- 3 attachments: traditional beaters and whisk
- 275 watts peak power
- 6 speeds with QuickBurst™ button
- Bowl Rest™ feature lets mixer sit on edge of bowl

Dimensions (inches): 9.6 H x 5.8 W x 9.4 D

Модель 62650. Шестискоростной ручной миксер с защелкивающимся кейсом.



FEATURES

- Snap-on storage case
- 290 Watts peak power makes mixing easy
- Convenient mixing features including QuickBurst™ button and Bowl Rest™
- Versatile attachment set includes traditional beaters, wire beaters and whisk
- Brushed stainless steel

Dimensions (inches): 10.5 H x 5.9 W x 9.7 D

Модель 62620. Шестискоростной ручной миксер с пульсирующим эффектом и защелкивающимся кейсом (черный).



FEATURES

- Snap-on storage case with easy-access door
- Pulse function — pulses on the slowest speed for added control and less mess
- 290 watts peak power with burst button
- 6 attachments included - twisted wire beaters, milkshake mixer, dough hooks, and whisk
- Convenient eject trigger for attachments

Dimensions (inches): 8.86 H x 3.54 W x 9.06 D

Модель 62621. Шестискоростной ручной миксер с пульсирующим эффектом и защелкивающимся кейсом (пурпурный).



FEATURES

- Snap-on storage case with easy-access door
- Pulse function — pulses on the slowest speed for added control and less mess
- 290 watts peak power with burst button
- 6 attachments included - twisted wire beaters, milkshake mixer, dough hooks, and whisk
- Convenient eject trigger for attachments

Dimensions (inches): 8.86 H x 3.54 W x 9.06 D

Модель 62623. Шестискоростной ручной миксер с пульсирующим эффектом и защелкивающимся кейсом (бирюзовый).



FEATURES

- Snap-on case
- 6 attachments - twisted wire beaters, milkshake mixer, dough hooks, and whisk
- Attachment eject trigger
- Quick Burst pulse button
- Bowl Rest
- 290 watts peak power
- Dishwasher safe parts

Dimensions (inches): 8.86 H x 3.54 W x 9.06 D

DETAILS

The Hamilton Beach® Performance Hand Mixer features twisted wire beaters designed for fast and easy mixing, and less clogging. The mixer has 6 speeds to make easy work of all your recipes, a QuickBurst™ button, and a pulse function. The mixer comes with everything you need to start mixing. You get 6 attachments and a snap-on storage case. The attachments include: 2 twisted wire beaters, a milkshake blending rod, dough hooks, and a whisk. A convenient eject trigger makes it easy to remove attachments for cleaning. The pulse function works on the slowest speed for added control and less mess. And the QuickBurst™ button gives you an extra burst of power when you need it. The mixer has 290 watts of peak power to easily handle every mixing job, whether you're combining ingredients for your favorite dip, making a batch of homemade cookies, preparing fresh bread dough, or whipping cream to top a delicious pie.

Beaters designed for fast and easy mixing

Twisted wire beaters are designed to mix faster and clog less.

Snap-on storage case and 6 attachments included

The hand mixer with storage case includes everything you need: twisted wire beaters, a milkshake blending rod, two dough hooks, and a whisk. All the accessories store neatly in the snap-on storage case.

6 speeds with quickburst™ button

This versatile electric hand mixer has 6 different speed options, plus a QuickBurst™ button for those times when you need an extra burst of power.

Pulse function

Pulse on the lowest speed for added control and less mess.

290 watts peak power

This Hamilton Beach hand mixer easily handles every mixing job, whether you're combining ingredients for your favorite dip, making a batch of homemade cookies, preparing fresh bread dough, or whipping cream to top a delicious pie.

Convenient eject trigger

Attachments easily and quickly eject from the mixer.

Модель 62632R. Ручной миксер с защелкивающимся кейсом.



FEATURES

- Snap-on storage case
- 3 attachments: 2 traditional beaters and 1 whisk
- 6 speeds with QuickBurst™ button
- Slower first speed reduces messy splatters
- Bowl Rest™ feature
- 275 Watts peak power
- Easy-access door for convenient storage

Dimensions (inches): 8.4 H x 3.3 W x 9.9 D

Модель 62683. Ручной миксер с защелкивающимся кейсом.



FEATURES

- Snap-on storage case for instant storage - no more lost beaters
- 250 Watts peak power
- 6 speeds with QuickBurst™ button
- Bowl Rest™ feature
- Traditional beaters and whisk

Модель 62692. Ручной миксер с защелкивающимся кейсом.

FEATURES



- Snap-on case with easy-access door
- No more lost attachments - includes traditional beaters and whisk
- Slower first speed reduces messy splatters
- 275 Watts peak power
- 6 speeds with QuickBurst™ button
- Bowl Rest™ feature

Dimensions (inches): 9.6 H x 5.8 W x 9.4 D

DETAILS

The Hamilton Beach® 6 Speed Hand Mixer with Snap-On Case comes with everything you need to start mixing: 2 dishwasher safe traditional beaters and a whisk. For easy storage, the snap-on storage case neatly holds the attachments to reduce the chance beaters are lost or misplaced. They'll always be on hand when you need them. This versatile hand mixer has 6 speed options for a wide range of mixing tasks, plus QuickBurst™ for when you need an extra burst of power. The hand mixer has 275 watts of peak mixing power to get the job done whether you're making a batch of homemade cookies, preparing mashed potatoes, or whipping cream to top a homemade pie. With this hand mixer, you'll easily mix and whip ingredients for your favorite recipes. A slower first speed helps keep ingredients in the bowl when mixing and is perfect for folding in dry ingredients like flour into cake batter or for combining liquids. The Bowl Rest™ feature conveniently stabilizes the mixer on the edge of the bowl when not in use to free your hands. The mixer has a nonskid heel that reduces tipping. From America's #1 hand mixer brand.* Rated 4.5 stars by consumers.

No more lost beaters

The snap-on storage case holds the included attachments, reducing the chance that beaters for the electric hand mixer get lost or misplaced. A convenient access door makes it easy to add attachments or remove them from the case.

Includes complete 3 piece attachment set

The Hamilton Beach hand mixer includes everything you need to start mixing. It comes with 2 dishwasher safe traditional beaters and a whisk. All the accessories store neatly in the snap-on storage case.

Reduce messy splatters

The hand mixer has a slower first speed that helps keep ingredients in the bowl when mixing. It's perfect for folding in dry ingredients like flour into cake batter or for combining liquids.

Mix and whip ingredients with ease

With 275 watts peak power, the hand mixer easily mixes and whips the ingredients for your favorite recipes, whether you're adding heavy ingredients like nuts to cookie dough or making light, fluffy meringue for a pie.

Versatile with 6 speeds & quickburst™

This versatile hand mixer with storage case has 6 different speed options for a wide range of mixing tasks, plus QuickBurst™ at any speed level for those times when you need an extra burst of power.

Модель 64699. Шестискоростной ручной/стационарный миксер марки Power Deluxe.

FEATURES



- 5 attachments included
- Doubles as a hand mixer - mixer unlocks from stand for mixing versatility
- Shift & Sitr™ bowl
- 275 Watts peak power
- QuickBurst™ button
- 4 quart glass bowl
- Includes beaters, whisk and dough hooks
- Bowl Rest™ mixer stabilizer

Модель 62637. Шестискоростной ручной миксер с футляром для хранения марки SoftScape.

FEATURES



- Classic styling with brushed stainless steel housing
- Snap-on storage case — no more lost attachments
- Also includes 2 traditional metal beaters
- 300 watt peak-power motor
- Quick Burst™ button
- Bowl Rest™ feature lets mixer rest on bowl's edge

Dimensions (inches): 10.5 H x 5.9 W x 9.7 D

DETAILS

With the Soft Scape™ Hand Mixer, you can mix without having to constantly stop to scrape the bowl. That's because its unique Soft Scape™ attachments thoroughly incorporate ingredients as you mix.

Soft Scape™ wire beaters & whisk:

- Mix ingredients thoroughly to reduce manual scraping with a spatula
- Specially coated stainless steel won't scratch bowls or nonstick pots
- Dishwasher safe

Модель 62649. Шестискоростной ручной миксер с функцией QuickBurst.



FEATURES

- Fast, easy mixing with 6 speeds and QuickBurst™ button
- Versatile mixing with 5 attachments
- Convenient storage case
- Mixing control and power with 300 watts and rubber grip
- Attractive stainless steel body goes with any décor
- Prevent messy drips when you add ingredients

Dimensions: 8.3 H x 5.1 W x 3.5 D

DETAILS

Whip up a fluffy meringue for a lemon pie or prepare hearty dough for a homemade pizza with the Hamilton Beach® 6 Speed Hand Mixer with Quick Burst™ Button. For fast, easy mixing, it has 6 speeds plus a QuickBurst™ button to provide additional power at any speed. Since it includes 5 mixing attachments, this versatile mixer is your go-to appliance for mixing, folding, whipping and kneading all your favorite recipes. This stylish mixer comes with a storage case that fits all the attachments and the mixer perfectly. The 2 traditional beaters take on cookie dough and cake batter with ease. If you're making bread, the 2 dough hooks help you knead the ingredients thoroughly. For whipping cream or beating egg whites, the whisk provides light, airy results every time. Mixing control and power are at your fingertips with 300 watts of power and a rubber grip handle, and the attractive stainless steel body goes with any decor. To make it easier to rest the mixer when adding additional ingredients, the Hamilton Beach® 6 Speed Hand Mixer With Quick Burst™ Button features a convenient Bowl Rest™ feature.

Fast, Easy Mixing with 6 Speeds and Quickburst™ Button

This versatile hand mixer has 6 different speeds to handle every mixing jog, plus a QuickBurst™ button to give you an extra burst of power at any speed.

Versatile Mixing with 5 Attachments

With 2 traditional beaters, 2 dough hooks and a whisk, this electric hand mixer gives you all the right tools for mixing, folding, beating, whipping and kneading.

Convenient Storage Case

Now you can neatly hold the Hamilton Beach hand mixer with storage case and all 5 attachments in one place — no more lost beaters.

Mixing Control and Power with 300 Watts and Rubber Grip

Power through all your mixing tasks with ease with the 300 watt motor and enjoy the comfort and control of a rubber grip handle.

Attractive Stainless Steel Body Goes with Any Décor

The stylish body is outfitted with classic stainless steel and provides long-lasting durability.

Модель 64650. Шестискоростной ручной/стационарный миксер.



FEATURES

- Doubles as a hand mixer
- 290 Watts peak power makes mixing easy
- Shift & Stir™ bowl
- Versatile attachment set includes traditional beaters, whisk and dough hooks
- Brushed stainless steel
- 4 qt. stainless steel bowl
- 6 speeds & QuickBurst™ button
- Bowl Rest™ mixer stabilizer

Dimensions (inches): 10.5 H x 5.9 W x 9.7 D

Модель 62695V. Шестискоростной ручной миксер с защелкивающимся кейсом.



FEATURES

- Slower first speed reduces messy splatters
- No more lost attachments - includes traditional beaters and whisk
- Easy-access door on case
- 275 Watts peak power
- 6 speeds with QuickBurst™ button
- Bowl Rest™ feature

Dimensions (inches): 9.9 H x 5.8 W x 9.4 D

DETAILS

The Hamilton Beach® 6 Speed Hand Mixer with Snap-On Case comes with everything you need to start mixing: 2 dishwasher safe traditional beaters and a whisk. For easy storage, the snap-on storage case neatly holds the attachments to reduce the chance beaters are lost or misplaced. They'll always be on hand when you need them. This versatile hand mixer has 6 speed options for a wide range of mixing tasks, plus QuickBurst™ for when you need an extra burst of power. The hand mixer has 275 watts of peak mixing power to get the job done whether you're making a batch of homemade cookies, preparing mashed potatoes, or whipping cream to top a homemade pie. With this hand mixer, you'll easily mix and whip ingredients for your favorite recipes. A slower first speed helps keep ingredients in the bowl when mixing and is perfect for folding in dry ingredients like flour into cake batter or for combining liquids. The Bowl Rest™ feature conveniently stabilizes the mixer on the edge of the bowl when not in use to free your hands. The mixer has a nonskid heel that reduces tipping. From America's #1 hand mixer brand.* Rated 4.5 stars by consumers.

No more lost beaters

The snap-on storage case holds the included attachments, reducing the chance that beaters for the electric hand mixer get lost or misplaced. A convenient access door makes it easy to add attachments or remove them from the case.

Includes complete 3 piece attachment set

The Hamilton Beach hand mixer includes everything you need to start mixing. It comes with 2 dishwasher safe traditional beaters and a whisk. All the accessories store neatly in the snap-on storage case.

Reduce messy splatters

The hand mixer has a slower first speed that helps keep ingredients in the bowl when mixing. It's perfect for folding in dry ingredients like flour into cake batter or for combining liquids.

Mix and whip ingredients with ease

With 275 watts peak power, the hand mixer easily mixes and whips the ingredients for your favorite recipes, whether you're adding heavy ingredients like nuts to cookie dough or making light, fluffy meringue for a pie.

Versatile with 6 speeds & quickburst™

This versatile hand mixer with storage case has 6 different speed options for a wide range of mixing tasks, plus QuickBurst™ at any speed level for those times when you need an extra burst of power.

Модель 62641. Шестискоростной ручной миксер с функцией QuickBurst.



FEATURES

- No more lost attachments
- Snap-on storage case
- Includes set of beaters and a whisk
- 290 Watts peak power
- Quick Burst™ button provides extra power at any speed
- Bowl Rest™ feature lets mixer sit on edge of bowl

Модель 62633R. Шестискоростной ручной миксер с защелкивающимся кейсом.



FEATURES

- Snap-on storage case with easy-access door for convenient storage
- 5 attachments: 2 traditional beaters, 2 dough hooks and 1 whisk
- 6 speeds with QuickBurst™ button
- Slower first speed reduces messy splatters
- Bowl Rest™ feature
- 275 Watts peak power

Dimensions (inches): 8.4 H x 3.3 W x 9.9 D

Модель 62682RZ. Ручной миксер с защелкивающимся кейсом.



FEATURES

- Snap-on storage case
- 250 Watts peak power
- Bowl Rest™ feature
- Six speeds with QuickBurst™ button
- Traditional beaters and whisk

Dimensions (inches): 9.2 H x 5.7 W x 8.3 D

DETAILS

Mix and whip with power, convenience and comfort.

Whip up an airy meringue or decadent cake with the Hamilton Beach® Hand Mixer. This versatile mixer is your go to appliance for mixing, whisking and folding. A built in bowl rest makes it easier to set the mixer down when adding ingredients. It also touts six speeds, including a burst function for additional power at any speed. The Hamilton Beach® Hand Mixer is not just about performance – it's also designed for easy storage. A convenient snap-on case keeps attachments together, so you don't have to search for them each time.

Snap-On Storage Case

No more digging through the drawers to find your mixer attachments. A storage case perfectly fits all the attachments and cord. It then snaps onto the mixer, keeping everything together in one place.

Bowl Rest

Take a pause to read the recipe or add the next ingredient without wondering where to set the mixer. A built in groove lets you rest the mixer over the bowl, so drips go where they belong and not all over your countertop.

Attachments Included

Get mixing and whisking right away. Easy to clean set of traditional beaters and a whisk are included.

Модель 64695N. Шестискоростной ручной/стационарный миксер марки Power Deluxe.



FEATURES

- Doubles as a hand mixer
- Shift & Stir™ bowl
- 275 Watts peak power
- QuickBurst™ button
- 4 quart glass bowl
- Includes beaters, whisk and dough hooks
- Bowl Rest™ mixer stabilizer
- Easy-clean rounded cord

Dimensions (inches): 14 H x 10 W x 13.4 D

По вопросам продажи и поддержки обращайтесь:

Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Казахстан (7273)495-231

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Таджикистан (992)427-82-92-69

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: hmh@nt-rt.ru || <https://hamiltonbeach.nt-rt.ru/>