

Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Казахстан (7273)495-231

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Таджикистан (992)427-82-92-69

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: hmh@nt-rt.ru || <https://hamiltonbeach.nt-rt.ru/>

Модель 33191. Мультиварка емкостью 10 литров.

FEATURES



- Perfect for feeding a crowd
 - XL 10 quart size
 - Dishwasher safe stoneware & glass lid
 - Warm, low & high settings
 - Full-grip, folding handles for easy carrying and compact storage
 - Ideal size for turkey & larger bone-in roasts
- 10 qt. capacity - fits a 10 lb. turkey or 12 lb. roast

Dimensions: 11.5 H x 15.75 W x 12.5 D

DETAILS

The Hamilton Beach® 10 Quart Slow Cooker's extra-large capacity is perfect for everything from game-day chili to your Thanksgiving turkey. The oval-shaped stoneware crock can fit up to a 10 lb. turkey or 12 lb. roast and is perfect for large-batch soups and stews. This slow cooker features low and high cook settings and a warm setting, ideal for buffets or when dinner ends up later than you planned. Full-grip, folding handles make it easy to carry, and both the stoneware crock and glass lid are dishwasher safe.

Extra Large Capacity

This slow cooker is just the right size for feeding a crowd at a potluck, making dinner for a large family or batch cooking. The oval-shaped stoneware can fit a variety of foods, like soups, stews and even a 12 lb. roast.

3 Temperature Settings

Cook your meal on Low or High; if your meal is done cooking before you're ready to serve it, switch to Warm so it maintains its temperature without overcooking.

Full-Grip, Folding Handles

Full-grip handles mean you can carry the slow cooker from the counter to the serving table easily. When it's time to put the slow cooker away, the handles fold down for easy storage in tight spaces.

Модель 33190. Мультиварка овальная емкостью 10 литров.

FEATURES



- Extra-large capacity is perfect for large crowds
- Fits a 10 lb. turkey or 12 lb. roast
- Dishwasher safe stoneware & glass lid
- Warm, low & high settings
- Full-grip, folding handles for easy carrying and storage

DETAILS

The Hamilton Beach® 10 Quart Slow Cooker's extra-large capacity is perfect for everything from game-day chili to your Thanksgiving turkey. The oval-shaped stoneware crock can fit up to a 10 lb. turkey or 12 lb. roast and is perfect for large-batch soups and stews. This slow cooker features low and high cook settings and a warm setting, ideal for buffets or when dinner ends up later than you planned. Full-grip, folding handles make it easy to carry, and both the stoneware crock and glass lid are dishwasher safe.

Extra Large Capacity

This slow cooker is just the right size for feeding a crowd at a potluck, making dinner for a large family or batch cooking. The oval-shaped stoneware can fit a variety of foods, like soups, stews and even a 12 lb. roast.

3 Temperature Settings

Cook your meal on Low or High; if your meal is done cooking before you're ready to serve it, switch to Warm so it maintains its temperature without overcooking.

Full-Grip, Folding Handles

Full-grip handles mean you can carry the slow cooker from the counter to the serving table easily. When it's time to put the slow cooker away, the handles fold down for easy storage in tight spaces.

Модель 33231. Мультиварка емкостью 3 литра (матово черная).

FEATURES



- Low, high, and keep warm settings
- Perfect size for 3 lb. chicken or 2 lb. roast
- Oval shape
- Black matte finish
- 3 quart capacity
- Dishwasher safe stoneware and glass lid

Dimensions (inches): 8.5 H x 12.8 W X 9.0 D

DETAILS

Create flavorful meals with minimal effort.

Eliminate mealtime stress with the Hamilton Beach® Slow Cooker, which saves you time and energy by making delicious foods while you go about your routine. And with a beautiful black matte finish, it will look great on the countertop or kitchen table. Enjoy hands-free cooking while meals practically make themselves; simply add your ingredients, choose between the low or high settings and let the slow cooker do the rest. When cooking is complete, switch to the keep warm feature to maintain the ideal temperature until you're ready to eat. After dinner, the removable stoneware and tempered-glass lid go in the dishwasher for easy cleanup.

Modern Design

The sleek black matte finish of the Hamilton Beach® Slow Cooker puts a modern spin on the classic kitchen tool. The oval-shaped crock is the perfect size for cooking a 3 pound chicken or 2 pound roast.

Three Settings

Cook on either low or high, and use the keep warm function to prevent dinner from getting cold before guests arrive for a potluck or the big game starts.

Dishwasher Safe

The stoneware and lid are dishwasher-safe, making easy work of removing stubborn food.

Модель 33556. Портативная мультиварка емкостью 3.7 литра.

FEATURES



- Reduce messy spills with Lid Latch™ strap
- Perfect for family meals
- Maintain the ideal temperature
- Cook flavorful meals with minimal effort — no watching needed
- Simple to clean
- 1 year limited warranty

Модель 33662. Мультиварка из нержавеющей стали емкостью 5.7 литра марки Stay or Go.

FEATURES



- 6 quart capacity
- Flexible Programming - More programming options than Crock-Pot® Smart-Pot®*
- Sear or brown meat on your stovetop ... then finish meal in your slow cooker
- Removable nonstick aluminum pan cooks directly on gas, electric, or ceramic stovetops and is oven safe
- Mix and match temperature settings with your choice of cooking times
- Easy-clean touch pad
- Removable nonstick aluminum pan - Makes stovetop searing easy and is oven safe

- One-pan convenience - Start and finish your meal in the same pan
- Delicious flavor - Taking the time to sear and brown food enhances the flavor of your finished dish
- Dishwasher safe pan and lid
- Temperature setting - Choose high, low, or warm
- Automatic keep warm - When cooking time is up, it automatically shifts to warm
- Time setting - Select 2, 4, 6, 8, or 10 hours of cooking time

* CROCK-POT® and SMART-POT® are registered trademarks of Sunbeam Products, Inc. Use of the CROCK-POT® or SMART-POT® trademark does not imply any affiliation with or endorsement by Sunbeam Products, Inc.

Dimensions (inches): 9 H x 17 W x 11 D

Модель 33665. Мультиварка емкостью 5.7 литра.

FEATURES



- 6 quart capacity
- Easy-to-hold full-grip lid and side handles
- Perfect size for a 6 lb. chicken or a 4 lb. roast
- 3 heat settings: high, low, and keep warm
- Removable stoneware
- Dishwasher safe stoneware and lid

DETAILS

Create flavorful meals with minimal effort.

Meals practically make themselves with the Hamilton Beach 6 Quart Slow Cooker. Simply add your ingredients, choose between the Low or High settings and let the slow cooker do the rest. When cooking is complete, switch to Keep Warm to maintain the ideal temperature until you're ready to eat. After dinner, the removable stoneware crock and tempered-glass lid go in the dishwasher for easy cleanup.

6 Quart Capacity

This slow cooker is just the right size for feeding the whole family. The oval-shaped 6 quart stoneware crock can fit a variety of foods, such as a 6 pound chicken or a 4 pound roast.

3 Temperature Settings

Cook your meal on Low or High; if your meal is done cooking before you're ready to serve it, switch to Keep Warm so it maintains its temperature without overcooking.

Full-Grip Handles and Lid

The full-grip handles makes carrying the slow cooker from the counter to the table easy.

Quick and Easy Cleanup

The removable stoneware crock and glass lid are both dishwasher safe, making cleanup a breeze.

Модель 33866. Мультиварка емкостью 5.7 литра марки Temp Tracker.

FEATURES



- Integrated probe track's your food's temperature for perfect results
 - Expand your cooking options: slow cook, braise, simmer, fondue, yogurt
 - Hold temperature option lets you braise, sous vide, simmer & more
 - Minimizes overcooking and helps ensure food safety when cooking beef, pork & poultry
 - Cook on low, medium, or high with or without temperature probe
- Clip-tight lid for easy travel
 - Perfect size for 6 lb. chicken or 4 lb. roast
 - Expand your cooking options with precise temperature control
 - **4 probe locations:** insert the probe in 1 of 4 areas, depending on what you're cooking
 - Convenient probe storage area
 - Integrated probe continually tracks the temperature of food
 - **Multiple cooking functions:** cook on low, medium, or high with or without the probe; when time is up, slow cooker shifts to warm
 - Countdown timer displays remaining cooking time
 - Temperature readout for current internal food temperature
 - **Hold temperature:** Holds food at a set temperature for the amount of time you select — perfect for sous vide, yogurt, fondue & more

DETAILS

Take all of the guesswork out of meal preparation with the Hamilton Beach Temp Tracker Slow Cooker. It offers all the traditional benefits of slow cooking, plus the ability to prepare food to a specific temperature and maintain it for up to 24 hours – great for sous vide, poaching, simmering, braising, fondue, yogurt and more. The digital display keeps you informed every step of the way, while the included temperature probe ensures your meal will always be prepared to your exact desired doneness, even if you're not home to tend to the meal when it's finished cooking.

Expand Your Cooking Options

Flexible cooking options, including a setting that holds food at a set temperature, allow you to slow cook, braise, sous vide, simmer, make fondue, poach, prepare yogurt and more.

Temperature Probe Prevents Overcooking

The integrated temperature probe continuously tracks the temperature of food during use, minimizing the chances of under- or overcooking. When your food is done, the slow cooker will either automatically switch to keep warm or hold your meal at the selected temperature, depending on your settings.

Digital Display

The digital display provides a clear readout of your food's current internal temperature when using the probe. If you selected a cook time, the countdown timer displays the remaining number of hours left.

6 Quart Capacity

The slow cooker's 6 quart capacity is the perfect size for a 6 pound chicken or a 4 pound roast.

4 Probe Locations

Insert the probe in one of four convenient spots, depending on what you're cooking.

Clip-Tight Lid

The lid clips tight for easy, mess-free travel to potlucks and tailgates.

Probe Storage Area

Integrated probe wraps around the lid's handle and store safely in the clip.

Модель 33140V. Мультиварка емкостью 3.7 литра.



FEATURES

- Dishwasher safe stoneware & lid for fast, easy cleanup
- 4 settings include off, low, high & warm
- Perfect size for a 4 lb chicken or two 2 lb roasts
- Stoneware is stainproof and removable for tabletop serving or refrigerator storage

Dimensions (inches): 9.2 H x 13.9 W x 9.2 D

Модель 33141. Мультиварка емкостью 3.7 литра.



FEATURES

- Dishwasher safe stoneware and lid
- 4 quart oval stoneware
- Keep warm setting
- Recipes included

Dimensions (inches): 9 H x 12.9 W x 9.6 D

Модель 33155. Портативная мультиварка емкостью 5 литров (красная).



FEATURES

- Reduce messy spills with Lid Latch™ strap & gasket lid
- Dishwasher safe stoneware and glass lid
- 5 quart capacity
- Keep warm setting
- Perfect size for a 4.5 lb chicken or two 2 lb roasts

Модель 33256. Портативная мультиварка емкостью 5 литров (черная).



FEATURES

- Reduce messy spills with Lid Latch™ strap
- Perfect size for a 4.5 lb chicken or two 2 lb roasts
- Dishwasher safe stoneware & glass lid
- 5 quart capacity
- Keep warm setting

Dimensions (inches): 8.8 H x 15.5 W x 10.6 D

Модель 33182. Мультиварка емкостью 7.5 литра (черная).



FEATURES

- Perfect for large meals
- Perfect size for a 6 lb roast or 8 lb chicken
- Mess-free lid rest for easy serving
- Full-grip handles
- Dishwasher safe stoneware & glass lid

Dimensions (inches): 11.6 H x 17.7 W x 11.6 D

DETAILS

Dinner for the whole family doesn't have to be a chore. With the Hamilton Beach® 8 Quart Slow Cooker, it can be as easy as putting a few ingredients in the crock before work and turning it on. By the time you come home, a warm, delicious, home-cooked meal will be waiting.

With an 8 qt. capacity, this slow cooker is ideal for families or feeding a crowd. It can easily accommodate a 6 lb. roast or an 8 lb. chicken. It is also perfect for bringing chili to a potluck or for sharing your latest and greatest dish with friends. It features low and high cook settings and a warm setting, ideal for buffets or when dinner ends up later than you planned.

The mess-free lid rest holds the lid up securely and directs drips back into the dish. Full grip handles make it easy to carry and both the stoneware and glass lid is dishwasher safe. Cook home-made meals for your family without having to spend the whole day in the kitchen ...now that's Good Thinking®.

Much more than just pot roast

Slow cookers have long been synonymous with pot roast and chili, but the options for great meals are endless with the Hamilton Beach® 8 Quart Slow Cooker. From casseroles to soups, lasagna to Asian pork, ribs to bread pudding, the sky is the limit.

Large Capacity

With an 8 quart capacity, this slow cooker is ideal for large meals or dishes to share.

Mess-free Lid Rest

Serving is simplified with our mess-free lid rest. Simply remove the lid and place it on the rest while serving.

Cord Wrap

Storage is a snap with the cord-wrap feature. Located on the back of the cooker, the cord is wrapped around a holder for easy storage.

Take it on the road with Lid Latch™

Lid Latch™ helps secure the lid while moving, transporting, or storing the slow cooker. It's simple to use. Simply stretch the latch from underneath one handle to the other. Cross at the middle for extra security, and you're ready to transport or store your slow cooker.

Perfect for entertaining at home or taking on the road.

Hamilton Beach® Slow Cookers take the convenience of slow-cooked dishes a giant step further. Several models of slow cookers, such as the Stay or Go® Slow Cooker, address one of your greatest concerns—getting your finished dish to a potluck or party without messy spills. Take a look at our line to see which slow cooker best fits your needs.

Even if you typically use your slow cooker at home, you'll be impressed by the attractive design, easy-to-use features and simple dishwasher cleanup that a Hamilton Beach® Slow Cooker offers you.

Модель 33184. Мультиварка емкостью 7.5 литра (красная).

FEATURES



- Perfect for large meals
- Dishwasher safe stoneware & glass lid
- Keep warm, low & high settings
- Full-grip handles
- Perfect size for 6 lb. roast or 8 lb. chicken

Dimensions (inches): 11.6 H x 17.7 W x 11.6 D

Модель 33002. Изолированная сумка для мультиварки Crock Caddy.

FEATURES



- Perfect for transporting hot meals
- Helps prevent messy spills
- Front opening simplifies loading the slow cooker
- Fits most 4 to 8 quart slow cookers— mesh cover net secures smaller slow cookers in place
- Handle openings & straps let you carry slow cooker 2 ways

DETAILS

Take your slow cooker anywhere.

From potlucks to parties, easily get your slow cooker meals from here to there with the Hamilton Beach® Crock Caddy™. This insulated bag keeps your food warm and in one place, so you can transport your slow cooker, worry-free. Designed for ultimate carrying convenience, the front of the caddy's case opens, making it simple to get your slow cooker in and out. The flexible material means you can fit different size slow cookers, from 4 to 8 quart. A mesh net secures smaller slow cookers in place. And with handle openings on both sides and sturdy straps, you can choose how to carry it.

Fits Most Slow Cookers

Oval or round, big or small - one size fits most with this case. It's adaptable to hold 4 to 8 quart sizes.

Interior Net for Extra Hold

An internal mesh net with Velcro enclosures secures smaller slow cookers in place.

Simple, Front Loading Design

Getting a warm crock in and out of a carrying bag just got a lot easier thanks to this caddy's front opening.

Two Ways to Carry Your Slow Cooker With Ease

- **By the Handles**

Handle openings on either side lets you carry your cooker by its handles.

- **With the Sturdy Straps**

Use the sturdy straps on the caddy.

Модель 33261. Мультиварка емкостью 3.7 литра марки Stay or Go (черная).



FEATURES

- Perfect size for 6 lb. chicken or 4 lb. roast
- Clip-tight sealed lid locks onto slow cooker to help prevent messy spills
- Bring 6 quarts of hot food to potlucks or parties anytime
- Removable stoneware and glass lid go in the dishwasher for easy cleanup
- Heavy-duty handles make carrying easier
- High, low & keep warm settings

Модель 33262. Мультиварка емкостью 3.7 литра марки Stay or Go.

FEATURES



- Clip-tight sealed lid for spill resistance
- Perfect size for 6 lb. chicken or 4 lb. roast
- Clip-tight sealed lid locks onto slow cooker to help prevent messy spills
- Bring 6 quarts of hot food to potlucks or parties anytime
- Removable stoneware and glass lid go in the dishwasher for easy cleanup
- Full-grip handles make carrying easier
- High, low & keep warm settings

Dimensions (inches): 9.8 H x 17.3 W x 11.1 D

DETAILS

No messy spills or leaks

The Stay or Go Slow Cooker offers additional thoughtful features that make traveling with your food to a pot-luck or holiday party a breeze, including a clip-locked, secure lid and tight seal for spill-resistant travel. Full-grip handles make carrying your dish to the party and back very easy. Back home, the stoneware removes for easy cleanup in the dishwasher.

Great for Any Occasion

Slow cookers are great for cooking chilis, soups and stews, but these "one-pot" meals are not the only things that slow cookers do well. They are also perfect for making side dishes and dessert, especially when your main oven is full, and they great for foods that are not naturally tender, such as inexpensive but flavorful meat cuts. If you choose cuts such as chuck roast, pork butt, short ribs or chicken thighs, you won't be disappointed with the results of low and slow cooking. Like braising, slow cookers tenderize meat gradually as it cooks.

Модель 33185. Мультиварка овальная емкостью 7.5 литра.

FEATURES



- Perfect for large meals
- Extra-large capacity
- Dishwasher safe stoneware & glass lid
- Warm, low & high settings
- Full-grip, folding handles for easy carrying and storage
- Perfect size for a 6 lb. roast or 8 lb. chicken

Dimensions: 16.56 H x 16.25 W x 10.18 D

DETAILS

Capacity for a crowd.

The Hamilton Beach 8 Quart Slow Cooker's extra-large capacity is perfect for game-day chili, holiday entertaining or sharing your latest and greatest dish with friends. It can easily accommodate a 6 lb. roast or an 8 lb. chicken.

This slow cooker features low and high cook settings and a warm setting, ideal for buffets or when dinner ends up later than you planned. Full-grip, folding handles make it easy to carry, and both the stoneware and glass lid is dishwasher safe.

Key Features

- Extra-large 8 quart capacity
- Warm, low & high settings
- Full-grip, folding handles for easy carrying and storage
- Dishwasher safe stoneware & glass lid
- Perfect size for a 6 lb. roast or 8 lb. chicken

Large, 8 Quart Capacity

This slow cooker is just the right size for feeding a crowd, satisfying the appetite of a large family or batch cooking. The oval-shaped stoneware can fit a variety of foods, such as an 8lb. chicken or a 6lb. roast.

Full-Grip, Folding Handles

The full-grip handles makes carrying the slow cooker from the counter to the serving table easy. When it's time to put the slow cooker away, the handles fold down for easy storage.

Dishwasher Safe For Quick and Easy Cleanup

The removable stoneware and glass lid are both dishwasher safe, making cleanup a breeze.

Модель 33666. Мультиварка овальная емкостью 5.7 литра (красная).

FEATURES



- 6 quart capacity
- Easy-to-hold full-grip lid and side handles
- Perfect size for a 6 lb. chicken or a 4 lb. roast
- 3 heat settings: high, low, and keep warm
- Removable stoneware
- Dishwasher safe stoneware and lid

DETAILS

Create flavorful meals with minimal effort.

Meals practically make themselves with the Hamilton Beach 6 Quart Slow Cooker. Simply add your ingredients, choose between the Low or High settings and let the slow cooker do the rest. When cooking is complete, switch to Keep Warm to maintain the ideal temperature until you're ready to eat. After dinner, the removable stoneware crock and tempered-glass lid go in the dishwasher for easy cleanup.

6 Quart Capacity

This slow cooker is just the right size for feeding the whole family. The oval-shaped 6 quart stoneware crock can fit a variety of foods, such as a 6 pound chicken or a 4 pound roast.

3 Temperature Settings

Cook your meal on Low or High; if your meal is done cooking before you're ready to serve it, switch to Keep Warm so it maintains its temperature without overcooking.

Full-Grip Handles and Lid

The full-grip handles makes carrying the slow cooker from the counter to the table easy.

Quick and Easy Cleanup

The removable stoneware crock and glass lid are both dishwasher safe, making cleanup a breeze.

Модель 33167. Мультиварка емкостью 5.7 литра.

FEATURES



- 6 qt. oval stoneware cooks a 6 lb. chicken, two 3 lb. roasts & more
- Keep warm setting maintains serving temperature
- Removable dishwasher safe stoneware and lid
- Lid Latch™ strap included for easier portability

Модель R1505. Мультиварка емкостью 5.7 литра.

FEATURES



- Re-certified Unit with full warranty
- Easy travel fewer spills
- Lid Latch™ strap included for easier portability
- Low, high and keep warm settings
- Removable dishwasher safe stoneware & glass lid
- Perfect for a 6 lb. chicken or 4 lb. roast

Модель 33176. Мультиварка овальная емкостью 6.7 литра.



FEATURES

- 7 qt. oval stoneware cooks an 8 lb. chicken, two 4 lb. roasts & more
- Keep warm setting maintains serving temperature
- Recipes included for meals, soups and side dishes
- Removable dishwasher safe stoneware and lid
- Lid Latch™ strap included for easier portability

Dimensions (inches): 7.7 H x 17.3 W x 11.5 D

Модель 33861. Мультиварка емкостью 5.7 литра марки Stay or Go.



FEATURES

- 3 programmable cooking options: FlexCook™, Program and Manuel, for ultimate cooking flexibility
- FlexCook™ mode: Select first heat setting & cooking time then select second heat setting & cooking time; automatically shifts to warm after cooking
- Program mode: Select one heat setting & cooking time, automatically shifts to warm after cooking
- Manual mode: high, low and warm settings
- Stay or Go® clip-tight sealed lid for easy transport
- Full-grip handles make carrying meals easier
- Perfect size for 6 lb. chicken or 4 lb. roast
- Power interrupt protection - keeps slow cooker on during a brief power outage
- Dishwasher safe stoneware & glass lid

DETAILS

Customize your cooking with FlexCook™.

Finally, a slow cooker that lets you program timing and heat setting to fit your schedule and your cooking style. With the FlexCook™ Slow Cooker from Hamilton Beach®, you can program two different heat settings and time durations in one cooking cycle, giving you greater flexibility in cooking your favorite recipes. For example, you can cook on high three hours, then low for six hours, or cook on low for four hours, then high for two.

Prefer to keep it simple? The FlexCook™ also offers a program mode for one heat setting and cooking time. The slow cooker automatically switches to warm when cooking time ends. There's also a manual mode, where you can select high, low or warm with no timer. And with Stay or Go® clips that lock onto the slow cooker and seal the lid, you can enjoy worry-free travel. Both the lid and crock remove easily and go into the dishwasher for cleanup.

How FlexCook Works

Select the First Heat Setting and Cooking Time

Press the FlexCook™ button then use the easy to ready digital display to choose high or low heat. Next, select the amount of time you want it to cook for at that temperature.

Then Program the Second

Use the other keypad to program your second heat setting and cooking time. Then press enter. During cooking, each screen will show the temperature setting and remaining cooking time.

Automatically Switches to Warm

Once your second cooking time is up, the slow cooker will automatically switch to warm – keeping your food hot until you're ready to serve.

Program and Manual Cooking Options, Too

In addition to the FlexCook™ setting, you can also choose the Program mode for setting a single temperature and time. Once your programmed time is up, the cooker will automatically switch to warm. Want to control the heat on your own? Use Manual to select the traditional warm, low or high settings with no time limit.

Mess-Free Travel

Keep your food in the crock, and not on your car floor, with the innovative Stay or Go® lid lock – once clipped into place, the locked lid creates a seal that prevents spills and leaks. The full-grip handles make carrying the slow cooker simple.

По вопросам продажи и поддержки обращайтесь:

Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Казахстан (7273)495-231

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Таджикистан (992)427-82-92-69

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: hmh@nt-rt.ru || <https://hamiltonbeach.nt-rt.ru/>