

Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Казахстан (7273)495-231

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Таджикистан (992)427-82-92-69

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: hmh@nt-rt.ru || <https://hamiltonbeach.nt-rt.ru/>

Модель 25475. Бутербродница (серая).



FEATURES

- Make a hot and hearty breakfast sandwich at home
- Ready to eat in 5 minutes or less
- Use your own fresh ingredients, including eggs, cheese & precooked meat*
- Cooks every layer of your breakfast sandwich to perfection
- Cooking plate cooks a fresh egg perfectly, then slides out to assemble your sandwich
- Make sandwiches with English muffins, biscuits, small bagels, and more
- All removable parts are dishwasher safe
- Surfaces are covered with durable, nonstick coating
- Questions are supported by a toll-free call center

located in the U.S.

- Backed with a one-year warranty

* *Meat used must be precooked*

Dimensions (inches): 5.6 H x 6.3 W x 7.3 D

DETAILS

They say breakfast is the most important meal of the day. Unfortunately, mornings are hectic for most people, especially families with children. So how do you cope with hunger pangs at breakfast time? If you're like most people, you have to rush through the meal, gobble down whatever's handy in the kitchen, or grab a quick, on-the-go bite.

That's where the Breakfast Sandwich Maker by Hamilton Beach comes to the rescue. It's all about making a fresh breakfast sandwich you can grab and go. Just choose your bread and layer on the fixings: egg, cheese, precooked meat, or the ingredients of your choice. In five minutes or less, your perfectly assembled breakfast sandwich is ready to eat. You can customize your breakfast sandwich with a practically endless variety of fresh ingredients. Now you know why everyone who loves breakfast sandwiches wants this product in their kitchen!

Don't let another morning go by without the Breakfast Sandwich Maker by Hamilton Beach. It lets you enjoy a homemade breakfast sandwich, made your way, in the comfort of your own kitchen. Cleanup is easy because all removable parts go in the dishwasher.

Модель 25477. Бутербродница (черная).

FEATURES



- Make a hot and hearty breakfast sandwich at home
 - Ready to eat in 5 minutes or less
 - Use your own fresh ingredients, including eggs, cheese & precooked meat*
 - Cooks every layer of your breakfast sandwich to perfection
 - Cooking plate cooks a fresh egg perfectly, then slides out to assemble your sandwich
 - Make sandwiches with English muffins, biscuits, small bagels, and more
 - All removable parts are dishwasher safe
 - Surfaces are covered with durable, nonstick coating
- Questions are supported by a toll-free call center located in the U.S.
- Backed with a one-year warranty

* Meat used must be precooked

Dimensions (inches): 5.6 H x 6.3 W x 7.3 D

DETAILS

They say breakfast is the most important meal of the day. Unfortunately, mornings are hectic for most people, especially families with children. So how do you cope with hunger pangs at breakfast time? If you're like most people, you have to rush through the meal, gobble down whatever's handy in the kitchen, or grab a quick, on-the-go bite.

That's where the Breakfast Sandwich Maker by Hamilton Beach comes to the rescue. It's all about making a fresh breakfast sandwich you can grab and go. Just choose your bread and layer on the fixings: egg, cheese, precooked meat, or the ingredients of your choice. In five minutes or less, your perfectly assembled breakfast sandwich is ready to eat. You can customize your breakfast sandwich with a practically endless variety of fresh ingredients. Now you know why everyone who loves breakfast sandwiches wants this product in their kitchen!

Don't let another morning go by without the Breakfast Sandwich Maker by Hamilton Beach. It lets you enjoy a homemade breakfast sandwich, made your way, in the comfort of your own kitchen. Cleanup is easy because all removable parts go in the dishwasher.

Модель 25476. Бутербродница (красная).

FEATURES



- Make a hot and hearty breakfast sandwich at home
- Ready to eat in 5 minutes or less
- Use your own fresh ingredients, including eggs, cheese & precooked meat*
- Cooks every layer of your breakfast sandwich to perfection
- Cooking plate cooks a fresh egg perfectly, then slides out to assemble your sandwich
- Make sandwiches with English muffins, biscuits, small bagels, and more
- All removable parts are dishwasher safe
- Surfaces are covered with durable, nonstick coating

- Questions are supported by a toll-free call center located in the U.S.
- Backed with a one-year warranty

* *Meat used must be precooked*

Dimensions (inches): 5.6 H x 6.3 W x 7.3 D

DETAILS

They say breakfast is the most important meal of the day. Unfortunately, mornings are hectic for most people, especially families with children. So how do you cope with hunger pangs at breakfast time? If you're like most people, you have to rush through the meal, gobble down whatever's handy in the kitchen, or grab a quick, on-the-go bite.

That's where the Breakfast Sandwich Maker by Hamilton Beach comes to the rescue. It's all about making a fresh breakfast sandwich you can grab and go. Just choose your bread and layer on the fixings: egg, cheese, precooked meat, or the ingredients of your choice. In five minutes or less, your perfectly assembled breakfast sandwich is ready to eat. You can customize your breakfast sandwich with a practically endless variety of fresh ingredients. Now you know why everyone who loves breakfast sandwiches wants this product in their kitchen!

Don't let another morning go by without the Breakfast Sandwich Maker by Hamilton Beach. It lets you enjoy a homemade breakfast sandwich, made your way, in the comfort of your own kitchen. Cleanup is easy because all removable parts go in the dishwasher.

Модель 25482. Бутербродница (мятная).

FEATURES



- Quick and Easy Easily create a breakfast, lunch, or dinner sandwich. Perfect for brunch or a quick meal on the go.
- Use Your Own Fresh Ingredients Customize your sandwich with your favorite bread, cheese, eggs, meats, and much more.
- Get Inspired Explore more than 25 sandwich maker recipes on our website.
- Just 4 Easy Steps Simply 1) add bread and precooked meat or cheese to the bottom cooking plate. 2) Crack an egg into the upper egg plate; then 3) layer the second piece of bread on top of the egg and close the lid. 4)

Once your sandwich is done cooking, just slide the egg plate out to assemble the sandwich.

- Easy Cleanup All removable parts are dishwasher safe; surfaces are covered with durable, nonstick coating.
- Ready to Eat in 5 Minutes Enjoy your custom sandwich in just 5 minutes!

Dimensions (inches): 8.3 H x 3.5 D

DETAILS

Forget the fast food drive-through. With the Hamilton Beach® Breakfast Sandwich Maker, you can enjoy a hot, homemade breakfast, lunch, or dinner sandwich in minutes using your own fresh ingredients. Simply build the base of your sandwich in the bottom layer, place the egg and your sandwich's top layer on the upper cooking plate, and close the lid. In just five

minutes, your breakfast sandwich is ready to eat. Explore more than 25 sandwich recipes on our website, from the traditional egg, ham, and cheese to more unique options like cheddar, apple, bacon, and egg croissant sandwich. All removable parts are dishwasher safe; surfaces are covered with durable, nonstick coating.

Quick and easy

This sandwich maker cooks your breakfast, lunch, or dinner sandwich in just minutes! Perfect for brunch or a quick meal on the go.

Use your own fresh ingredients

Use this breakfast sandwich maker to completely customize your sandwich with your choice of bread, cheese, eggs, meats, and much more.

Get inspired

Explore more than 25 sandwich maker recipes on our website.

Just 4 easy steps

Building your breakfast sandwich comes together in just a few steps with a breakfast maker — and you don't even need to leave your house.

Easy cleanup

All removable parts on this sandwich maker are dishwasher safe and surfaces are covered with durable, nonstick coating.

Модель 25483. Бутербродница (коралловая).



FEATURES

- Quick and easy
- Use your own fresh ingredients
- Recipes on our website
- Just 4 easy steps
- Easy cleanup
- Ready to eat in 5 minutes

Dimensions (inches): 8.3 H x 3.5 D

DETAILS

Forget the fast food drive-through. With the Hamilton Beach® Breakfast Sandwich Maker, you can enjoy a hot, homemade breakfast, lunch, or dinner sandwich in minutes using your own fresh ingredients. Simply build the base of your sandwich in the bottom layer, place the egg and your sandwich's top layer on the upper cooking plate, and close the lid. In just five minutes, your breakfast sandwich is ready to eat. Explore more than 25 sandwich recipes on our website, from the traditional egg, ham, and cheese to more unique options like cheddar, apple, bacon, and egg croissant sandwich. All removable parts are dishwasher safe; surfaces are covered with durable, nonstick coating.

Quick and easy

This sandwich maker cooks your breakfast, lunch, or dinner sandwich in just minutes! Perfect for brunch or a quick meal on the go.

Use your own fresh ingredients

Use this breakfast sandwich maker to completely customize your sandwich with your choice of bread, cheese, eggs, meats, and much more.

Get inspired

Explore more than 25 sandwich maker recipes on our website.

Just 4 easy steps

Building your breakfast sandwich comes together in just a few steps with a breakfast maker — and you don't even need to leave your house.

Easy cleanup

All removable parts on this sandwich maker are dishwasher safe and surfaces are covered with durable, nonstick coating.

Модель 25490. Бутербродница двойная.

FEATURES



- Quick and easy
- Makes 1 or 2 sandwiches
- Ready in 5 minutes*
- Cook delicious breakfast sandwiches in the comfort of your own home
- Use your own fresh ingredients, including eggs, cheese, and much more
- Countdown timer with audible beep
- Quick and easy recipes included
- Easy cleanup - all removable parts are dishwasher safe

* Meat used must be precooked

Two sandwiches are better than one

Nobody likes to wait for breakfast, especially kids. Now you can make and serve two hot and toasty sandwiches at the same time. The sandwiches can each be customized to individual tastes, so each person can have their favorite. Even if you don't have time to sit down and eat breakfast at home, in about five minutes you can have two sandwiches to go for taking to work or school. Cooking for one? The Breakfast Sandwich Maker can prepare a single sandwich, too.

Control what's inside your breakfast sandwiches

Do you really know what's inside all those restaurant, drive-thru, and store-bought sandwiches? Thanks to the Breakfast Sandwich Maker, wondering about questionable or mysterious ingredients is no longer an issue. That's because starting now, you can quickly and easily make a breakfast sandwich (or two) with your own fresh ingredients. Just preheat the Breakfast Sandwich Maker, add your choice of ingredients, and in five minutes or less, breakfast is ready.

Go healthy or hearty, depending on your mood

If you want to explore healthy breakfast alternatives and eat less processed food, the Breakfast Sandwich Maker can help. Your sandwiches could include whole-grain English muffins or bagels, low-fat cheese, egg whites, and your choice of veggies, lean meat, or a

vegetarian option. On the other hand, when you want to indulge in a satisfying, protein-packed sandwich, the Breakfast Sandwich Maker is ready to oblige. To make this kind of breakfast sandwich, use a whole egg and layer on your favorite cheese and meat. You can even use a pancake as the bread and pour syrup on your finished sandwich. What you make and how you eat it is completely up to you. Since you can make two at once, each can be customized to your liking.

Make breakfast sandwiches the easy way

If you've ever prepared breakfast sandwiches at home, you know it's a multi-step process often requiring more than one pan and a toaster for the bread. And that means you'll have to clean multiple pans, too. On mornings when you have extra time and energy to spare, that's fine. But what about mornings when you don't? You can still whip up two delicious breakfast sandwiches, thanks to the five-minute cooking time and easy cleanup. Know exactly how long until breakfast is ready, the built-in timer can be set in half-minute increments. A tone sounds when your sandwiches are ready.

Unlimited combinations for any taste

The versatility of combining fresh ingredients makes the Breakfast Sandwich Maker the perfect breakfast solution for people of all ages. You can customize every sandwich to the person, child, day of the week, or mood. People who own one say that they have fun experimenting with different foods and flavors to make unique sandwich combinations. However, if you're not inclined to create your own breakfast sandwich recipe, you're in luck.

Easy Cleanup

Unplug unit when finished cooking and allow to cool. Use a plastic or wooden utensil to loosen any baked-on ingredients. To remove the ring assembly for cleaning in the dishwasher or by hand, hold bottom handle to open, then lift straight up. For easier cleanup, spray rings and cooking plate with nonstick spray before use and after washing.

Tips for use

Extra-large eggs or very cold ingredients may lengthen cooking time. Higher-fat content bread, fewer ingredients, scrambled eggs, egg whites, and precooked ingredients may shorten cooking time. Do not use appliance unattended. Close supervision is necessary when any appliance is used by or near children. During use, provide 4 to 6 inches of air space above, behind, and on both sides for air circulation. Unplug from outlet when not in use.

DETAILS

They say breakfast is the most important meal of the day. Unfortunately, mornings are hectic for most people, especially families with children. So how do you cope with hunger pangs at breakfast time? If you're like most people, you have to rush through the meal, gobble down whatever's handy in the kitchen, or grab a quick, on-the-go bite.

That's where the Hamilton Beach® Dual Breakfast Sandwich Maker comes to the rescue. It's all about making fresh breakfast sandwiches you can grab and go. Just choose your bread and layer on the fixings: egg, cheese, precooked meat, or the ingredients of your choice. Cook two breakfast sandwiches to perfection and to your preferences, and know when it's ready with the built-in digital timer.

In five minutes or less, two perfectly assembled breakfast sandwiches are ready to eat. You can customize each of your breakfast sandwiches with a variety of fresh ingredients. Cleanup is easy because all removable parts go in the dishwasher.

По вопросам продажи и поддержки обращайтесь:

Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Казахстан (7273)495-231

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Таджикистан (992)427-82-92-69

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: hmh@nt-rt.ru || <https://hamiltonbeach.nt-rt.ru/>