

Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Казахстан (7273)495-231

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Таджикистан (992)427-82-92-69

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: hmh@nt-rt.ru || <https://hamiltonbeach.nt-rt.ru/>

Модель 76610. Аккумуляторная электрическая открывалка для вина.



FEATURES

- With foil cutter
- Remove corks with the touch of a button
- Cordless and portable - Lets you easily open wine bottles anywhere
- Foil cutter quickly removes foil and stores on base
- Ergonomic nonslip grip One-touch opening - With simple up/down button
- Opens up to 30 bottles when fully charged
- Charging base - Green light indicates when fully charged

Dimensions: 11 H x 4.25 W x 4 D

DETAILS

Removes corks with the touch of a button.

The Hamilton Beach Cordless Electric Wine Opener uncorks bottles with just the push of a button. It is cordless and portable, so you can open bottles of wine in the kitchen during holiday parties or out on the deck for summer cookouts. A foil cutter and recharging base are included.

How It Works:

- Remove foil with included foil cutter
- Position the wine opener and push the up/down button
- The wine opener will neatly extract your cork

Rechargeable Base

Place the electric wine opener on the charging base when not in use; the green light lets you know when the unit is fully charged. The electric wine opener can open up to 30 bottles when fully charged.